2-Phase Stepping Motor Driver

2M542

OPERATING MANUAL

Correctif de la page 5 du datasheet

Micro-Steps (for 1.8° basic step)

SW5	SW6	SW7	SW8	Step Mode	Steps/Rev
OFF	**ON**	**ON**	**ON**	1/2	400
ON	OFF	**ON**	**ON**	1/4	800
OFF	OFF	**ON**	**ON**	1/8	1600
ON	**ON**	OFF	**ON**	1/16	3200
OFF	**ON**	OFF	**ON**	1/32	6400
ON	OFF	OFF	**ON**	1/64	12800
OFF	OFF	OFF	**ON**	1/128	25600
ON	**ON**	**ON**	OFF		1000
OFF	**ON**	**ON**	OFF		2000
ON	OFF	**ON**	OFF		4000
OFF	OFF	**ON**	OFF		5000
ON	**ON**	OFF	OFF		8000
OFF	**ON**	OFF	OFF		10000
ON	OFF	OFF	OFF		20000
OFF	OFF	OFF	OFF		25000